
ENCE353: Introduction to Structural Analysis

Homework #4 Solutions


Problem 1: For a cantilever beam shown below:



Use the *method of moment-area* to calculate the vertical displacement at point B, assuming the EI is constant along the beam.

Solution:


(1) Draw the moment diagram:




(2) Calculate the deflection at point B:

$$\Delta_{\!\scriptscriptstyle B}\!=rac{rac{1}{3}\cdot 2L\cdot 2wL^{\,2}}{EI}\! imes\!rac{3}{4}2L=rac{2wL^{\,4}}{EI}(\downarrow)$$

Problem 2 For a cantilever beam shown below:




- (1) Use the *method of moment-area* to calculate the vertical displacement at point B, assuming the EI is constant along the beam.
- (2) Based on the results of (1), calculate the reaction force at point B for the following propped-cantilever beam, assuming the EI is constant along the beam:



Solution:


(1) Draw the moment diagram:



Calculate the deflection at point B:


$$arDelta_{\!\scriptscriptstyle B} = rac{rac{1}{2} \cdot L \cdot L}{EI} \cdot \left(rac{2}{3} \, L + L
ight) = rac{5}{6} rac{L^3}{EI} (\downarrow)$$

(2) The propped-cantilever beam can be decomposed by the following two simple beams:



For the first beam, we can use the principle of superposition based on the solution in (1). Now, we are dealing with the second one:

Draw the moment diagram with unknown reaction force R_B:



Calculate the deflection at B:


$$\Delta_{\!\scriptscriptstyle B} = rac{rac{1}{2} \cdot 2L \cdot R_{\scriptscriptstyle B} \cdot 2L}{EI} \cdot \left(rac{2}{3} \cdot 2L
ight) = rac{8}{3} rac{R_{\scriptscriptstyle B} L^3}{EI} (\uparrow)$$

Because the real structure will have zero deflection at point B, thus:

$$\Delta_{\!\scriptscriptstyle B}\!=\!rac{5}{6}rac{PL^{\,3}}{EI}-rac{8}{3}rac{R_{\!\scriptscriptstyle B}L^{\,3}}{EI}\!=\!0 \Rightarrow R_{\!\scriptscriptstyle B}\!=\!rac{5}{16}P(\uparrow)$$

Problem 3 For a simple supported beam shown below:


- (1) Use the *method of moment-area* to calculate the rotation at point A.
- (2) Use the *method of moment-area* to calculate the vertical deflection at mid-span. Solution:
- (1) Draw the moment diagram:



Calculate the rotation at A (note: the rotation at mid span will be 0 due to symmetry):

$$egin{align} heta_{ extit{ iny MID}} - heta_{ extit{ iny A}} &= rac{rac{1}{2} \cdot L \cdot PL}{EI} + rac{L \cdot PL}{2EI} = rac{PL^{\,2}}{EI} \ &\Rightarrow heta_{ extit{ iny A}} &= -rac{PL^{\,2}}{EI} \ \end{aligned}$$

(2) Calculate the deflection at mid span:



$$extstyle \Delta_{\! extstyle MID} = rac{rac{1}{2} \cdot L \cdot PL}{EI} \cdot \left(rac{1}{3}L + L
ight) + rac{L \cdot PL}{2EI} \cdot rac{1}{2}L = rac{11}{12}rac{PL^3}{EI}$$

According to geometry:

$$egin{align} heta_{A} &= rac{arDelta_{MID} + \delta_{MID}}{2L} \ \Rightarrow & \delta_{MID} &= heta_{A} \cdot 2L - arDelta_{MID} = rac{PL^2}{EI} \cdot 2L - rac{11}{12} rac{PL^3}{EI} = rac{13}{12} rac{PL^3}{EI} \ \end{split}$$