## Analysis of Beam Structures

Mark A. Austin

University of Maryland

austin@umd.edu ENCE 353, Spring Semester 2023

February 22, 2023




## Overview

- 1 Types of Beam Structure
- Connection to Mechanics
- 3 Relationship between Shear Force and Bending Moment
  - Mathematical Preliminaries
  - Derivation of Equations
- 4 Examples


# **Types of Beam Structure**

## Types of Beam Structures

#### Simply Supported Beam:




#### Cantilever:






## Types of Beam Structures

## Supported Cantilever:



#### Fixed-Fixed Beam Structure:





## Types of Beam Structures

#### **Boundary Conditions**

Simply Supported Beam

• 
$$y(0) = y(L) = 0$$
.

Cantilever Beam

• 
$$y(0) = 0$$
,  $\frac{dy}{dx}|_{x=0} = 0$ 

Supported Cantilever Beam


• 
$$y(0) = y(L) = 0$$
,  $\frac{dy}{dx}|_{x=0} = 0$ 

Fixed-Fixed Beam

• 
$$y(0) = y(L) = 0$$
,  $\frac{dy}{dx}|_{x=0} = \frac{dy}{dx}|_{x=L} = 0$ 

## **Basic Questions**


#### **Q1.** What is the relationship between inputs and outputs?



Decisions will be based on estimates of outputs.

## **Basic Questions**

Typical problem: Given input parameters, compute y(x), find location and magnitude of  $y_{min}$  and  $y_{max}$ .




For simple problems, can rely on intuition. Otherwise, need math and mechanics.



## Basic Questions

**Q2.** What is the relationship among the outputs? Are they dependent?




We will need to work with a chain of dependencies.


**Q3.** What is the relationship between V(x) and M(x)? Are they independent? No!

We will see:  $V(x) = \frac{dM(x)}{dx}$ , but not always true!


## Connection to Mechanics


#### **Problem Setup**





#### **Stress-Strain Relationships**







## Connection to Mechanics

For design purposes we need to make sure:

$$\sigma_{tension} < \sigma_{max \ tension}$$
 (1)

and

$$\sigma_{compression} < \sigma_{max}$$
 compression (2)

Also,

$$\epsilon_{\text{max compression}} \le \epsilon(y) \le \epsilon_{\text{max tension}}$$
 (3)

These constraints limit the amount of load that a beam can carry.

## Connection to Mechanics


#### Section-Level Behavior

From a design standpoint we can reduce  $\sigma(y)$  and  $\epsilon(y)$  by increasing the moment of interia in

$$\sigma(y) = \left[\frac{My}{I}\right]. \tag{4}$$

To maximise I, maximize distance of material from neutral axis.


Poor Choice of Inertia




## Assumptions on Beam Displacements

**Assumptions.** We will assume beam length / depth  $\gg 10$ .

Therefore, displacements will be dominated by flexural bending.





Sections remain perpendicular to the deformed neutral axis.

This is not the case for shear deformations.

## Relationship between Shear Force and Bending Moment

#### **Basic Questions**


- Are V(x) and M(x) independent? No!
- Under what conditions does a dependency relationship exist?

#### Strategy

- Introduce relavant mathematics.
- Extract a thin section from a beam and examine its equilibrium.
- See where the mechanics takes us!

Types of Beam Structure

**Taylor Series Expansion.** Let y = f(x) be a smooth differentiable function.



Given f(x) and derivatives f'(a), f''(a), f'''(a), etc, the purpose of Taylor's series is to estimate f(x + h) at some distance h from x.

Examples

The Taylor series is as follows:

$$f(x+h) = \sum_{k=0}^{\infty} \frac{f^{k}(x)}{k!} h^{k} = f(x) + f'(x)h + \frac{f''(x)}{2!} h^{2} + \frac{f'''(x)}{3!} h^{3} + \cdots$$
(5)

For a Taylor series approximation containing (n+1) terms

$$f(x+h) = \sum_{k=0}^{k=n} \frac{f^k(x)}{k!} h^n + O(h^{(n+1)})$$
 (6)

The big-O notation indicates how quickly the error will change as a function of h, e.g.,  $O(h^2) \rightarrow \text{magnitude}$  of error proportional to h squared.

**Finite Difference Derivatives.** Truncating equation 6 after two terms gives:

$$f(x+h) = f(x) + f'(x)h + O(h^{2}).$$
 (7)

A simple rearrangement of equation 7 gives:

$$\frac{dy}{dx} = \lim_{h \to 0} \left[ \frac{f(x+h) - f(x)}{h} \right]. \tag{8}$$

Similarly, we require:

$$\frac{dy}{dx} = \lim_{h \to 0} \left[ \frac{f(x) - f(x - h)}{h} \right]. \tag{9}$$

In order for the derivative to exist, equations 8 and 9 need to be the same!

Simple Example. Let  $v = x^2$ .


$$\frac{dy}{dx} = \lim_{h \to 0} \left[ \frac{(x+h)^2 - x^2}{h} \right] = \lim_{h \to 0} [2x+h] = 2x.$$
 (10)

**Home Exercise.** Use first principles to find dy/dx when:

$$y(x) = (x^2 - 4x + 3)^2 (11)$$

**Counter Example.** y(x) = |x| is not differentiable at x = 0.

## Test Problem for Derivation of Equations





## erivation of Equations

**Part 1:** Equilibrium in Vertical Direction:

$$\sum F_y = 0 \rightarrow V(x) - V(x + dx) - w(x)dx = 0$$
 (12)

From the Taylors series expansion:

$$V(x+dx) = V(x) + \frac{dV}{dx}dx + O(dx^2)$$
 (13)

Plugging equation 13 into 12 and ignoring higher-order terms:

$$\sum F_y = 0 \rightarrow V(x) - \left[V(x) + \frac{dV}{dx}dx\right] - w(x)dx = 0 \quad (14)$$

## Derivation of Equations

Hence.

$$\frac{dV}{dx} + w(x) = 0 \leftarrow \text{gradient of shear force equals -w(x)}.$$
 (15)

**Part 2:**  $\sum M_o = 0$  (anticlockwise +ve)

$$-V(x)dx - M(x) + M(x + dx) + w(x)dx \cdot \frac{dx}{2} = 0$$
 (16)

#### Note:

- The term w(x)dx is the vertical load acting on the element.
- The term dx/2 is the distance from O to the centroid of loading.

## **Derivation of Equations**

From the Taylor Series expansion:

$$M(x + dx) = M(x) + \frac{dM}{dx}dx + O(dx^2)$$
 (17)

Plugging equation 17 into 16 and ignoring terms  $O(dx^2)$  and higher:

$$V(x) = \frac{dM}{dx} \leftarrow \text{shear force} = \text{gradient of bending moment.}$$
 (18)


**Note.** Equation 18 only applies when the derivatives of M(x) with respect to x exist.

Examples


## Derivation of Equations

Types of Beam Structure

#### Illustrative Example



#### Bending Moment Diagram



**Interpretation.** Consider an interval [a, b] on a beam:

$$dV = -w(x)dx \to \int_a^b dV = -\int_a^b w(x)dx = V(b) - V(a).$$
 (19)

**Key Point:** Change in shear force between points a and b = total loading within interval.


$$dM = V(x)dx \to \int_{a}^{b} dM = \int_{a}^{b} V(x)dx = M(b) - M(a).$$
 (20)

**Key Point:** Change in moment between points a and b = area under the shear force diagram.

Examples

# **Examples**

#### Example 1.



Check Shear Loading (a = 0, b = L):

$$V(b) - V(a) = V(L) - V(o) = -wL = -\int_0^L w_o dx. \checkmark$$
 (21)



Check Relationship between Shear and Bending Moment:

$$V(x) = \frac{dM(x)}{dx} = w_o(L - x). \tag{22}$$

For a = 0 and b = L we expect:

$$\int_0^L V(x)dx = w_o \int_0^L () dx = M(L) - M(0).$$
 (23)

For a general value x:

$$M(x) = w_o \int_x^L (L-s) ds = w_o Lx - \frac{1}{2} w_o x^2 + A.$$
 (24)

Apply Boundary Conditions:

$$M(L) = 0 \to A = -\frac{1}{2}wL^2.$$
 (25)

Hence.

$$M(x) = wLx - \frac{1}{2}wx^2 - \frac{1}{2}wL^2 = -\frac{1}{2}w(L - x)^2.$$
 (26)

Check Moment at Boundary Conditions:

• 
$$M(L) = wL^2 - \frac{1}{2}2wL^2 = 0$$
.  $\checkmark$ 

• 
$$M(0) = -\frac{1}{2}wL^2$$
.

#### **Physical Interpretation**

For the extracted element:

$$\sum F_y(x) = 0 \to V(x) = w_o(L - x).$$
 (27)


Similarly,

$$\sum M_z(x) = 0 \to M(x) = \underbrace{w_o(L-x)}_{\text{total load}} \cdot \underbrace{\frac{(L-x)}{2}}_{\text{centroid}}$$
(28)


## Shear Force and Bending Moment Diagrams



Bending Moment (drawn on tension side of element):




Shear Force:






#### Example 2.



Bending Moment at x = L/2 (extract substructure):



Taking moments:

$$M(L/2) = \underbrace{\frac{w_o L}{2}}_{reaction} \underbrace{\frac{L}{2}}_{loading\ centroid} - \underbrace{\frac{w_o L}{4}}_{loading\ centroid} = \frac{w_o L^2}{8}.$$
 (29)



## Equation for M(x)?

We have:

- Axis of symmetry at x = L/2.
- M(x) will have roots at x = 0 and x = L.


Hence, let M(x) = Ax(x - L), then use midpoint moment to determine A:

$$M(L/2) = A\frac{L}{2}\left(\frac{-L}{2}\right) - > A = -\frac{w_o}{2}.$$
 (30)

Thus.

$$M(x) = \frac{w_o}{2} x (L - x).$$
 (31)

#### Example 3.



#### Bending Moment Diagram

